

32050 Balance Support

Purpose:

This kit is designed to support a standard lever clamp.

Required Accessories:

Lever Clamps

Assembly:

Attach tubes to base by inserting screws through the side of the base with the recessed holes. Next place washer over screw and screw tube onto base. Tighten screws until snug. Thread the remaining screws into the top of the tubes. The slots in the screws should be at the same height and in line with each other, as the slots are used to support the lever clamp.



Note: The further the screws are threaded into the top of the tubes, the more stable the support will be.

Time Allocation:

To prepare this product for an experimental trial should take less than five minutes. Actual experiments will vary with needs of students and the method of instruction, but are easily concluded within one class period.

Feedback:

If you have a question, a comment, or a suggestion that would improve this product, you may call our toll free number.